

Panel Widths & Layout

PANEL WIDTH CHART									
NUMBER OF BEARING BARS	BEARING BAR SPACING				NUMBER OF BEARING BARS	BEARING BAR SPACING			
	1-3/16" O.C.	15/16" O.C.	11/16" O.C.	7/16" O.C.		1-3/16" O.C.	15/16" O.C.	11/16" O.C.	7/16" O.C.
6	6-1/8"	4-7/8"	3-5/8"	2-3/8"	26	29-7/8"	23-5/8"	17-3/8"	11-1/8"
7	7-5/16"	5-13/16"	4-5/16"	2-13/16"	27	31-1/16"	24-9/16"	18-1/16"	11-9/16"
8	8-1/2"	6-3/4"	5"	3-1/4"	28	32-1/4"	25-1/2"	18-3/4"	12"
9	9-11/16"	7-11/16"	5-11/16"	3-11/16"	29	33-7/16"	26-7/16"	19-7/16"	12-7/16"
10	10-7/8"	8-5/8"	6-3/8"	4-1/8"	30	34-5/8"	27-3/8"	20-1/8"	12-7/8"
11	12-1/16"	9-9/16"	7-1/16"	4-9/16"	31	35-13/16"	28-5/16"	20-13/16"	13-5/16"
12	13-1/4"	10-1/2"	7-3/4"	5"	32	SHADED AREAS INDICATE STOCK PANEL WIDTHS	29-1/4"	21-1/2"	13-3/4"
13	14-7/16"	11-7/16"	8-7/16"	5-7/16"	33		30-3/16"	22-3/16"	14-3/16"
14	15-5/8"	12-3/8"	9-1/8"	5-7/8"	34		31-1/8"	22-7/8"	14-5/8"
15	16-13/16"	13-5/16"	9-13/16"	6-5/16"	35		32-1/16"	23-9/16"	15-1/16"
16	18"	14-1/4"	10-1/2"	6-3/4"	36		33"	24-1/4"	15-1/2"
17	19-3/16"	15-3/16"	11-3/16"	7-3/16"	37		33-15/16"	24-15/16"	15-15/16"
18	20-3/8"	16-1/8"	11-7/8"	7-5/8"	38		34-7/8"	25-5/8"	16-3/8"
19	21-9/16"	17-1/16"	12-9/16"	8-1/16"	39		35-13/16"	26-5/16"	16-13/16"
20	22-3/4"	18"	13-1/4"	8-1/2"	40			27"	17-1/4"
21	23-15/16"	18-15/16"	13-15/16"	8-15/16"	41			27-11/16"	17-11/16"
22	25-1/8"	19-7/8"	14-5/8"	9-3/8"	42		28-3/8"	18-1/8"	
23	26-5/16"	20-13/16"	15-5/16"	9-13/16"	53		35-15/16"	18-9/16"	
24	27-1/2"	21-3/4"	16"	10-1/4"	83			36-1/16"	
25	28-11/16"	22-11/16"	16-11/16"	10-5/8"					

WIDTHS SHOWN ARE FOR 3/16" THICK BEARING BARS. FOR 1/8" BEARING BARS, DEDUCT 1/16" FROM THE VALUES INDICATED.

